



ASSEMBLY INSTRUCTION










ITEM#:5599-71/5599N-71



DESCRIPTION:DINING TABLE

5599/5599N-71T DINING TABLE TOP


5599/5599N-71B DINING TABLE BASE

5599/5599N-71M DINING TABLE PLATE



NO.	PARTS LIST			QTY	NO.	HARDWARE LIST		QTY
						HARDWARE PACK IN 5599-71T		
1		DINING TABLE TOP	1		A		ALLEN BOLT M6*16MM	2
					B		HEX NUT M8	4
2		DINING TABLE BASE	2		C		FLAT WASHER	4
					D		LOCK WASHER	4
3		DINING TABLE BASE	1		E		ALLEN KEY 4MM	1
					F		HEX NUT WHEEL WRENCH M8	1
4		DINING TABLE BASE	2		G		METAL ROD	4
					H		BRACKET	2
5		DINING TABLE BASE	1		I		LEVELER	6
6		DINING TABLE PLATE	1					




STEP 1




STEP 2





STEP 3



STEP 4



STEP 5



STEP 6



Please always lift up the table from the center to avoid tipping/dropping or imbalance causing damages or injuries.

! For items use on wooden floor,hard surfaces or carpets,it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration
Do not tighten bolts until completely assembled