








Assembly Instruction

ITEM NO.: 8348GRY/DGY-2
Double Reclining Love seat With
Center Console & Cup holders




Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


COMPONENT LIST

| No | Drawing | Description | Qty |
|----------|---|--------------------------|-------|
| A |  | SEAT | 1 PC |
| B |  | LSF BACK REST | 1 PC |
| C |  | CONSOLE BACK REST | 1 PC |
| D |  | RSF BACK REST | 1 PC |
| E |  | LSF EAR | 1 PC |
| F |  | RSF EAR | 1 PC |
| G |  | STAR KNOB | 2 PCS |


Step #1




Step #2



Step #3



COMPLETED



Care Instruction for Corduroy Furniture:

In order to maintain the original appearance of your Corduroy Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Corduroy.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.