







# Assembly Instruction




Power Reclining Chair With USB Port  
ITEM NO.: 8479BEG-1PW

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.


## Component list

| No | Drawing   | Qty | Description |
|----|---|-----|-------------|
| A  |    | 1   | Seat        |
| B  |  | 1   | Backrest    |
| C  |  | 1   | Adaptor     |
| D  |  | 1   | Plug        |


THE PARTS ARE LOCATED INSIDE THE BOX AS BELOW:



## Step #1




## Step #2



### Step #3

Assembly completed.



## Care Instruction for Chenille Furniture:

In order to maintain the original appearance of your chenille fabric, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage chenille. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.