

ASSEMBLING INSTRUCTIONS

ITEM NO: 9155GY-OT

Ottoman with Caster


Â

Casters and hardwares are stored at the bottom of the ottoman, please unzip the bottom seat cover and take out for assembly.


Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.

COMPONENT LIST


NO	DRAWING	DESCRIPTION	QTY
Α		OTTOMAN	1 PC
В		CASTER	4 PCS
С	4HHHH (B)	SCREW ø1/4" x 3/4"L	16 PCS




STEP 3:



STEP 4: Completed.



STEP 5:



Care Instruction for Textured Fabric Furniture:

In order to maintain the original appearance of your textured fabric, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage textured fabric. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.