


ASSEMBLY INSTRUCTIONS

SH3815GRY-2
Reclining Loveseat with console and USB, Gray



PARTS LIST

PART	DRAWING	DESCRIPTION	QTY	PART	DRAWING	DESCRIPTION	QTY
A		SEAT	1	E		LEFT WING	1
B		LEFT BACKREST	1	F		RIGHT WING	1
C		CONSOLE BACKREST	1				
D		RIGHT BACKREST	1				




Reclining Loveseat with console and USB, Gray

THE PARTS ARE LOCATED INSIDE THE BOX AS BELOW:




STEP 1




Attach the Backrest (B/D) to the Seat (A).

STEP 2




Attach the Left wing (E) and Right wing (F) to Left Backrest (B) and Right Backrest (D).

STEP3



Attach the Console backrest (C) to the Seat (A)

STEP4



Open the Footrest by PULL out the handle.

ASSEMBLY COMPLETED