
# ITEM # SH3811GRY-1/ SH3811BRN-1/ SH3811GYPU-1 POWER LIFT RECLINER

## **ASSEMBLY INSTRUCTIONS**



**RECLINER W/ POWER LIFT** 

#### **PARTS LIST**

PART	DRAWING	DESCRIPTION	QTY
A		SEAT	1
В		BACKREST	1
С		LSF WING	1
D		RSF WING	1

PART	DRAWING	DESCRIPTION	QTY
E		WIRE	1
F		ADAPTOR	1
G		PLUG WITH WIRE	1
Н		REMOTE CONTROL	1


#### NOTES

- 1. CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
- ${\tt 2. \, REMOVE \, ALL \, COMPONENTS \, FROM \, THE \, PACK \, AND \, PLACE \, ON \, A \, CLEAN, \, SOFT \, SURFACE \, TO \, ASSEMBLE.}$
- 3. UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
- 4. DO NOT OVER TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
- 5. WITH USE, SCREW MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.



## ITEM # SH3811GRY-1/ SH3811BRN-1/ SH3811GYPU-1 POWER LIFT RECLINER

### **ASSEMBLY INSTRUCTIONS**



#### NOTES


- 1. CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
- 2. REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
- 3. UNITE SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
- 4. DO NOT OVER TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
- 5. WITH USE, SCREW MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.




# ITEM # SH3811GRY-1/ SH3811BRN-1/ SH3811GYPU-1 POWER LIFT RECLINER

### **ASSEMBLY INSTRUCTIONS**

## STEP 1 Attach the Backrest (B) to the Seat (A).



STEP 2 Attach the Wing (C/D) to the Backrest (B).



STEP 3 Connect the Remote & Power strip w/ the Power source. Open reclining w/ remote function.

