

ASSEMBLY INSTRUCTION

ITEM NO : 9649BE-VT/9649DG-VT

(1/3) Reversible 2-seater with pull-out bed (Backrest and Pillow are stored in 9649BE-VC/9649DG-VC)

9649BE-VC/9649DG-VC

1

2

2

1

4

4

1

1

1

1

2

2

1

1

4

22

16

Not Included

Packed in 9649BE-VT/9649DG-V SCREW M4 x 25MM

Packed in 9649BE-VT/9649DG-VT

Ν

(2/3) Reversible chaise with hidden storage.


9649BE-A/9649DG-A


(3/3) Two arms


Legs and hardware are stored in the box, please take out for assembly

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or crcking the wood. 2-SEATER PART LIST

Location of KD parts










STEP 4

Please note the positions of Loveseat (A) and Chaise (G) can be changed/ reversible









ASSEMBLY INSTRUCTION

ITEM NO : 9649BE-VT/9649DG-VT 9649BE-VC/9649DG-VC 9649BE-A/9649DG-A


STEP 8







Completed.



Care Instruction for Fabric Furniture:

In order to maintain the original appearance of your Fabric furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Fabric.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.
- For item use on wooden floor, hard surfaces, or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.