

ASSEMBLY INSTRUCTION

ITEM NO.:8457BEG/BLK/GRY-2PW



Power Double Reclining Love Seat with Center Console,
Wireless Speakers, LED and Charging Ports




Hardware are stored in box,
please take out for assembly.

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.

COMPONENT LIST

NO.	Sketch	QTY	Description	NO.	Sketch	QTY	Description
A		1 PC	Seat	E		1 PC	Left EAR
B		1 PC	Left Backrest	F		1 PC	Right EAR
C		1 PC	Right Backrest	G		1 PC	chair adaptor
D		1 PC	Console Backrest	H		1 PC	Speaker adaptor
I		2 PCS	Female bracket				




ASSEMBLY INSTRUCTION

ITEM NO.:8457BEG/BLK/GRY-2PW

Power Double Reclining Love Seat with Center Console,
Wireless Speakers, LED and Charging Ports


STEP 1:

Align metal bracket on back to the base, push to the end to secure in position.
NOTE: Console backrest(D) is packed in the bottom of base. Please take out for assembly.




STEP 2:

Attach Left Backrest (B) and Right Backrest(C) to the Seat Body(A).




STEP 3:

Attach the Left EAR(E) and Right EAR(F) to the Backrest(B) and Backrest(C)



STEP 4:

Connect the power cord




ASSEMBLY INSTRUCTION

ITEM NO.:8457BEG/BLK/GRY-2PW

Power Double Reclining Love Seat with Center Console,
Wireless Speakers, LED and Charging Ports


STEP 5:



Thank you for using Remo1 Bluetooth sound system.
Before using this unit please read the instruction carefully.
This audio system is for indoor use only.
Do not attempt to modify, repair it, please contact store or customer service if you have any issue.
Trying to remove panels or repairing the unit could result electric shock, property damage and injury.
Please connect the unit directly to wall outlet, do not use extension cord.
As for how to pair Bluetooth speaker, please refer to the Instruction Manual

Led Light

STEP 6:




ASSEMBLY INSTRUCTION

ITEM NO.:8457BEG/BLK/GRY-2PW

Power Double Reclining Love Seat with Center Console,
Wireless Speakers, LED and Charging Ports

STEP 7:
Completed



Care instruction on for PU furniture:

In order to maintain the original appearance of your PU furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating or heating conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage PU.
- Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use windows, radiators, or vents.
- Vacuum or wipe with a cloth regularly to remove dust.



For items used on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.

Warning!

Do not allow electrical cord to be pinched between moving parts or between the frame and the floor. Do not place cord under carpet or in location where it could become worn.

To avoid damage, please use scissors to remove this tag